



# DIGITAL LAP COUNTER

## INSTRUCTIONS




◀ The Lap Counter operates using power gained from the track – batteries are not required.

As soon as the Lap Counter powers up, the first of the red numbers will flash. Up to 999 laps can be programmed.



1. Place cars behind the START line. ▶
2. Press the button marked + to change the first number.
3. Press the button marked ▶ to move to next number, then + to change.
4. Repeat (3) for the last number; then press ▶ to accept (if you need to start again, press ▶ once more to return to the beginning).
5. Press START. There is a 5 second countdown to GO. (The lap counter "beeps" as it counts down – the final "beep" for GO is longer and higher pitched).

The first lap will not register until the cars have completed the circuit and passed the FINISH line. The green display will register the leading cars' ID. This will change if a different car takes over the lead. (An illuminated green "dot" will pulse until the race finishes).



4th Place  
3rd Place  
2nd Place  
Winning Car ID

◀ When the race has ended, the ID of the winning car will flash in the green display. 2<sup>nd</sup>, 3<sup>rd</sup> and 4<sup>th</sup> place cars will register in the red display from right to left.

To race again with the same number of laps, just press START. Otherwise, press ▶ and re-program as described in 1-5 above.

**IMPORTANT** If using this Lap Counter with the 6-Car Digital Powerbase, please note that IDs for the winner and runners up will display as above – 5<sup>th</sup> and 6<sup>th</sup> placed cars will not be displayed.

### SAFETY NOTES

- This product is not suitable for children under 3 years of age because of small parts which can present a choking hazard. Some components have functional sharp edges – handle with care.
- This product is intended for indoor use only.
- Do not use standard power bases or power supplies in a Sport Digital layout as this will seriously damage the Sport Digital equipment.
- The power supply transformer is not a toy. It is a "Transformer for Toys". Before use, check that the transformer is the correct voltage for your mains electricity supply. The set is only to be used with the recommended transformer. The transformer should be examined regularly for damage to the casing, plug pins and cables. **In the event of such damage, the set should not be used until the transformer is replaced with a new Hornby recommended unit. Never attempt to open the transformer yourself.**
- The set must not be connected to more than the recommended number of power supplies. The output terminals of the transformer must not be connected directly, or indirectly, to the output of any other circuit derived from a transformer or mains power supply.
- If the electric motor in the car becomes jammed, remove the car from the track and let it cool down. Do not touch the motor casing.
- Before cleaning any part, disconnect the transformer from the mains electricity supply. **Do not use liquid for cleaning.**
- Please retain these details for future reference.

### HORNBY PRODUCT GUARANTEE

Hornby products are guaranteed against defects in materials or workmanship for a period of six months from purchase. To qualify for the guarantee, the product must have been used and maintained according to the manufacturers instructions. If any such defect occurs during the period of guarantee then return to the address below or contact via [www.hornby.com](http://www.hornby.com) or [www.scalextric.com](http://www.scalextric.com) or phone 01843-233525.

Alternatively, the product (or component), may be forwarded to Hornby Hobbies Limited, carefully packed, with a covering letter enclosed giving full details to: Repairs Department, Hornby Hobbies Limited, Westwood, MARGATE, Kent CT9 4JX, United Kingdom. Please obtain a Certificate of Posting at the time of dispatch. Subject to the exclusions below, the product will be repaired or replaced free of charge.

**Exclusions:** The fault has been caused or is attributable to mis-use, negligent use or used contrary to the manufacturers recommendations. Accidental physical damage.

This guarantee is valid for products purchased in the United Kingdom and is in addition to, and does not diminish, your statutory rights. For further information about your statutory rights contact your local authority Trading Standards Department or Citizens' Advice Bureau.

### CUSTOMER CARE

Please contact Hornby Customer Care using any of the following methods:

- Phone us      Hornby Helpline: +44 (0) 1843 233525
- Write to us    Hornby Hobbies Ltd., Westwood Industrial Estate, Margate, Kent CT9 4JX, United Kingdom
- Email us        [customercare@hornby.com](mailto:customercare@hornby.com)  
                      [customercare@hornby-usa.com](mailto:customercare@hornby-usa.com)
- Internet        Alternatively, please check the Scalextric website for updates and frequently asked questions about Sport Digital.  
                      [www.scalextric.com](http://www.scalextric.com)  
                      [www.scalextric-usa.com](http://www.scalextric-usa.com)